

Installation instructions for the N/Line FJR accessory Dash



1. Raise windscreen to its highest position or until the screw that holds the front and center access cover is exposed. (This cover is right above the headlight)

2. Just remove the screw. Do not remove the cover. **(Illustration 1)**

3. Remove the 2 upper most screws on the left and right of the fairing. These 2 screws hold the black filler panels on the cockpit side of the fairing. They are the two that are recessed. **(Illustration 2)**

4. If there is a nylon flat washer lying down inside the recess, remove it for proper fit.

5. Remove the 2 screws, left and right inside fairing, directly below the 2 recessed screws. **(Illustration 5)**

6. Apply nylon disc to center of fairing, 1½" down from the top lip. **(Illustration 6)**

7. Put the 2 machined spacers in the upper recesses where you removed the 2 fasteners in step 3. **(Illustration 7)**

8. a. Install the left and right supports using a 20mm long screw at the lowest point first. Space this connection point with 1 rubber washer (against the painted fairing panel) and a nylon washer between the rubber and the support. Use the flat washer between the screw head and the support. Tighten this until snug but not tight. Make sure the middle formed tab is on top of the machined bushing.

b. Use the 40mm screw and a flat washer for the middle connection through the machined spacer.

c. Leave both connections a few rotations from snug for now.

9. This step will require you to position 2 rubber washers over and inline with the hole that secures the front access cover on the front of the fairing. (Step 1). Put 1 rubber washer in the covers recess, then take another rubber washer, wet it with some saliva and stick it to the top of the 1st washer. This will hold them in place until you put the 20mm thru the dash and into this hole being careful to not displace the washers.





10. Carefully lower the platform into position between the windscreen and the fairing until the screw hole lines up with the hole in the front of the fairing. Insert a 20mm long screw, flat washer optional. (**Illustration 10**)
11. Start the screw (only a few turns).
12. Lower the large or shelf end making sure the support brackets go inside the left and right flanges of the platform. (**Illustration 12**)
13. Insert the two 10mm long screws, washers, and Ny-lok nuts, attaching the brackets the shelf. (Use the washer for the nut-side of the connection) Snug these 2 screws but don't tighten.
14. Now start tightening all of the hardware. Start with the lower bracket screws. Then tighten the single screw in the front of the fairing (don't over do this one). Thirdly tighten the upper bracket connections using a socket to hold the Ny-lok nut. Make sure you have a flat washer between the bracket and the nut.
15. Lastly, tighten the middle two screws, the ones that pass through the spacer in the recess.
16. Go back and check all fasteners one final time. Now you are ready to mount the gadgets! You will most likely need to remove the platform again to drill holes for your brackets etc.
17. Congratulations you are ready to enjoy many miles of riding with your *N/Line* dash!

Thank you very much for your purchase.